

Figure 1

FIG. 4 is a perspective view of a handheld electronic device 400, such as a PDA, showing the front face. The device 400 includes a display screen 406, a keypad 404, and various other features. The display screen 406 shows a user interface with a clock 430, a battery level indicator 432, and a list of applications including Address, Calc, Date Book, Expense, Graffiti, HotSync, Mail, Memo Pad, Prefs, Security, The Scan, and To Do List. The keypad 404 includes a home button 436, a search button 438, and a magnifying glass button 442. The device 400 also includes a camera 420, a microphone 422, and a speaker 428. The device 400 is shown in a closed position, with the keypad 404 and display screen 406 visible.




Figure 4




Figure 2




Figure 3



Figure 5




Figure 6




Figure 7






Figure 8






Figure 9




Figure 10




Figure 11



Figure 12






Figure 13




Figure 14




Figure 15






Figure 16